


FC8 Chassis – Card Reader Installation



The FC8 has three single USB headers that need connecting to your motherboard, two for the dual USB slots and one for the card reader.

The image below shows how to connect the three headers onto the correct pins on your motherboard's USB header:



Each USB header on your motherboard will accept two single USB headers.